

CT-ST61A

Swagging Tool Drill Bit Kit

6 Piece Copper Tube Expander 1/4", 3/8", 1/2", 5/8", 3/4" and 7/8"

Product Instructions



STEP 1

According to the inner diameter of the pipe and the process requirements, select the appropriate type of expander.

STEP 2

Insert the hex handle of the expander into the hand drill interface and clamp it, then start to screw it forward.



STEP 3

Screw it to the handle cover of the expander, and exit to complete the expansion.