



P/N: DC-810

Relay, Overload and Start Capacitor Combo

3 in 1 START from 1/12 to 1/5 HP

Refrigerators / Freezers Domestic & Commercial

Installation Instruction:

1. Remove power supply cord.
2. Remove old relay and overload.
3. Push the pin terminal connected to white wire on RCO onto start terminal of compressor.
4. Push pin terminal connected to red wire on RCO onto run terminal of compressor.
5. Push pin terminal connected to black wire on RCO onto start terminal of compressor.
6. Connect one line wire which was removed from old relay to one of the line wires of the RCO using wire nut.
7. Connect other line wire which was removed from the old overload to other live wire of the RCO using wire nut.

277VAC. 22A Max.

