



## P/N: SK-5

Relay and Hard Start Capacitor  
Increases Compressor Torque 300%

This product can be used on all PSC single phase, 115V thru 230VAC.  
Air Conditioning Units from 4,000BTU to 120,000BTU (1/2 thru 5HP)

### **Installation Instruction:**

Connect the two wires from SK-5 in parallel with the run capacitor (one wire each) without removing any original wire. Use special "Piggy Black" terminal of the SK-5 if all the capacitor terminals are being used.

**INSTALL ONLY ON PSC UNITS EQUIPPED WITH RUN CAPACITOR.**

277VAC. 22A Max.  
No wiring changes  
necessary.

